

PAX door handle installation

The holes for the handles are pre-drilled, but you still need to drill them through yourself.

To prevent the material from breaking loose while drilling, it is important to clamp a wooden board against the door.

Required

- Clamp
- Wooden board
- 4mm drill bit + drill

Carefull secure the wooden board with clamps.
Nou user the grill bit to krill the hole all the way through.

